

# TRIC TAG II INSTRUCTIONS

1. Determine location for Tric Tag II to be installed on vehicle.
2. The 90 degree bracket has two mounting holes that need to be marked on vehicle at mounting locations. Drill holes to size and use fasteners provided. Welding in place is an option to fasteners.
3. Uncoil the red and orange wires and run along or through the vehicle frame to an opening in the vehicle, close to the ignition switch or fuse panel. The red wire connects to the battery side and the orange connects to the ignition side. The green wire is to be grounded to the vehicle frame.
4. If the optional bar tag light is used, one wire needs to be secured to a good grounding location and the other wire spliced into the tail light wire.

*NOTE: Tric Tag II has a built in safety feature - should the tag be subjected to a hard forward or backward hit, a disc spring washer has been installed on the motor shaft to allow the tag mount plate to move without harming the motor.*

**Warning: Do not tamper with any part of linkage or open the lid to the motor box. Doing so could result in unit malfunctioning, and warranty being voided!**

Good Time Productions will be held harmless from any liability incurred by the owner/operator of Tric Tag II that might originate because of the product's operation or because of any federal, state, or local ordinances.

