


47-54 Chevy Pickup
Bolt in Crossmember


PLEASE READ INSTRUCTIONS COMPLETELY BEFORE STARTING YOUR INSTALLATION
NOTE: This kit is designed for use with power steering and the full type lower control arms only.

Kit Contents	
	ADJUSTER ASSEMBLY (2)
	INNER BOXING PLATE - LEFT
	INNER BOXING PLATE - RIGHT
	SPRING TOWER - LEFT
	SPRING TOWER - RIGHT
	47-54 BOLT IN CRADLE
	GAGE PLATE
	OUTER BOXING PLATE (2)
	HARDWARE KIT



47-54 Chevy Pickup
Bolt in Crossmember


1.
Start by supporting the car on four jack stands.
2.
Remove all the suspension and steering components from the frame. Leave the front spring shackle mounts that are riveted in the frame. They are used for a measuring point for finding your axle centerline.
3.
The rear portion of the radiator support needs to be trimmed for rack and pinion clearance. This can be trimmed without removing the support from the frame, although we found it easier to remove the entire radiator support. This can be accomplished by grinding the heads of the rivets flush with the frame rail then center punching the center of the rivets and drilling a 5/16" diameter hole about 1/4" deep. Using a hammer and punch you can drive out the rivets.
4.
Trim the rear portion of the radiator support per illustration. If the radiator support was entirely removed from the frame the rivet holes will need to be drilled out to 25/64" and bolted back in using 3/8" nuts and bolts (not included). The lower flanges on the frame rails will need to be trimmed also; they taper and get wider toward the front radiator support. Trim the lower flanges flush with the trimmed radiator cross member per illustration.



47-54 Chevy Pickup
Bolt in Crossmember


5.

Measure straight back 18-1/8" from the center of both front spring shackle holes and scribe a vertical line on the frame as shown in the illustration. Using a long straight edge; line up both of the vertical lines and scribe a line on the top of the frame rails. This is the cross member centerline.




6.

Take the cross member and slide it up in between the frame rails centering the cross member on the scribed axle centerline.
NOTE: The rack mounts are on the front side of the cross member. Clamp in place making sure the cross member fits flush with the bottom of the frame rail. See illustration.




7.

Using a 25/64" drill, drill out the four outer holes of the cross member through the frame rails. Temporarily bolt the cross member in place using four 3/8"-24 x 1" bolts and set up nuts. See illustration. Remove the clamps, mark and drill the four lower mounting holes on the bottom of the cross member using the same 25/64" drill. See illustration.



8.

Remove the cross member and temporarily bolt the drilling template to the outside of the frame rails using the 3/8" bolts and set up nuts. The c-notch in the template goes toward the front. Mark and drill the eight 25/64" holes in the template through the frame rails. Using the template as a guide, scribe the lines on the outside and the bottom of the frame rails for the c-notches. Trim the c-notches per illustration.



INSTRUCTIONS

© 2019, Speedway Motors, Inc.


SPEEDWAY
motors®

91044754

47-54 Chevy Pickup
Bolt in Crossmember


9.

Slide the channeled boxing plates into the frame rails lining up the c-notch on the boxing plates with the c-notch in the frame. If necessary trim the frame to fit around the c-notch. See illustration.



10.

Slide the cross member up in between the frame rails and into position lining up the eight mounting holes on the cross member with the eight holes on the inner boxing plates. Using the 3/8"-24 x 1 bolts and 3/8"-24 lock nuts, bolt them together but do not fully tighten. See illustration.




11.

Line up the four mounting holes on the bottom of the cross member with the four holes on the bottom of frame rail and inner boxing plates. Using a rubber mallet, you can tap the inner boxing plates into position. Install the 3/8"-24 x 1 bolts and 3/8"-24 lock nuts through the four mounting holes but do not fully tighten.

12.


Slide the inner boxing plates in between the frame rails and the outer boxing plates lining up the outer four mounting holes on the cross member. Install four 3/8"-16 x 1-1/4" bolts and nylock nuts do not fully tighten. See illustration.



13.

Bolt both spring towers onto the frame rails using the outer eight mounting holes. Use the 3/8"-24 x 1-1/4" bolts and 3/8"-24 lock nuts. Make sure the spring towers fit flush to the top of the frame rail.

NOTE the spring towers are taller in the front and angle downward toward the rear. See illustration.



14.
Tighten all the 3/8" mounting bolts and nuts.

15.
Using a 25/64" drill, drill out the four upper spring tower mounting holes and install the 3/8"-24 x 1" bolts and lock nuts. See Illustration.

16.
Drill the final four 25/64" mounting holes through the frame rails and the channeled outer boxing plates per illustration. Locate the upper holes 3-1/8" forward from the center of the upper spring tower bolt centering it in the middle of the frame rail. The lower hole is located 5/8" forward of the c-notch in the bottom of the frame again centering it on the frame rail. Bolt together using the 3/8"-24 x 1-1/4" bolts and lock nuts. See Illustration.



IF YOU ARE USING THE OPTIONAL THREADED ADJUSTERS SKIP TO STEP #20

17.
Bolt the upper shock mounts into position from the bottom side of the spring tower using the 1/4"-28 x 3/8" button head bolts.
NOTE: make sure you use loctite on the threads.

18.
Install all the Mustang II suspension components to complete the installation. This bolt in cross member is designed to use the after market type full lower control arms only.

THREADED ADJUSTERS

20.
Slide the threaded adjuster sleeve into position from the bottom side of the spring towers. Bolt it in using the six 1/4"-28 x 3/8" button head bolts. NOTE: make sure you use loctite on the threads. Install the adjuster sleeve by threading it in from the bottom side of the spring tower and adjusting it to the midpoint. Install the grease zerks and the set screws into the adjuster ring and grease the adjusters.



47-54 Chevy Pickup
Bolt in Crossmember

21.

Install all the Mustang II suspension components to complete the installation. This bolt in cross member is designed to use the after market type full lower control arms only.

22.

To adjust the height, take all the weight off the springs. This means jacking the front suspension up off the ground and possibly unhooking the shocks. A spring compressor may also be helpful in this procedure. Make sure you support the car with jack stands. Loosen the set screw and turn the adjusting sleeve to the new position. The adjustment can be used to raise or lower the car, but it is designed to compensate for differing springs. For the correct geometry the lower control arms should be parallel to the ground with all the weight on the suspension. Once the suspension is set tighten the set screws.

Once the ride height is set have the front end aligned.

Caster 3° + for power steering

Camber $\frac{1}{2}^{\circ}$ +

Toe in + or - $\frac{1}{8}$

Once you have a couple of hundred of miles on the car it may be necessary to once again adjust the ride height due to the setting of the new front coil springs. The lower control arms must remain parallel to the ground for good geometry and prolonged ball joint life. Remember to loosen the set screw and grease the adjuster.

IMPORTANT

DISCLAIMER In an effort to offer our customers low prices, quick service and great value, Speedway Motors reserves the right to change suppliers, specifications, colors, prices, materials without notice. Prices and policies that were current and in effect at the time of printing are also subject to change without notice. Quantities are limited on some items. Any unauthorized use of this catalog including words, photos or drawings is prohibited. Speedway is not responsible for any typographical errors, printing errors or misinterpretations.

WARRANTY DISCLAIMER Purchasers understand and recognize that racing parts, specialized street rod equipment, and all other parts and services sold by Speedway Motors, Inc. are exposed to many and varied conditions due to the manner in which they are installed and used. Except for certain limited warranties, if any, set forth in Speedway Motors, Inc.'s current catalog with respect to the products and/or parts thereof identified on your invoice, each product, and each part thereof, is sold "as is", and "with all faults" and Speedway Motors, Inc. makes no warranties either expressed or implied, written or oral, with regard such products and services including, without limitation, any warranty of merchantability or fitness for a particular purpose. Without limiting the foregoing, there is no warranty expressed or implied as to whether the goods sold hereby will protect purchasers or ultimate end-users of such products and parts from injury or death. In no event shall Speedway Motors, Inc. be liable for any special, incidental or consequential damages, or any other damages whatsoever arising out of or connected with the use or misuse of the products and each part thereof. Purchasers acknowledge and agree that no person, entity or agent of Speedway Motors, Inc. has any authority to make any statement contrary to this disclaimer and that any warranty statements or representations allegedly made on behalf of Speedway Motors, Inc. by any such person, entity or agent are void. Purchasers are relying solely on their own skill and judgment to select, purchase and use suitable products and assume all responsibility and risk with regard thereto. Some local laws prohibit the use of utility jugs, funnels and barrel pumps for dispensing fuel. Please check your own state for more information, regulations or further direction in your use of the utility jugs, funnels and barrel pump described in Speedway's catalogs or on Speedway Motors websites. Some parts in this catalog are not legal for sale or use in California. Items sold in this catalog are for racing vehicles which may never be used on a highway. The use of manufacturer's names and symbols are for reference purposes only.

DAMAGE CLAIMS Please inspect all packages upon delivery and in the presence of the delivery driver when possible. The driver must note any visible damage and provide procedures for handling damage claims. To allow for a claims process, please retain original box, packing material and damaged merchandise. Contact Speedway Motors for instructions regarding damage claim within 5 days of receipt. Speedway Motors assumes no liability after this period.

SHORTAGES Please check the contents of your delivery to ensure that all parts ordered are received. Refer to your invoice to cross check all items received and inspect all packing materials for contents of small items. Retain original shipping box and packing materials. Orders may be split into multiple boxes which can be delivered on different days. Contact Speedway Motors for instructions regarding shortage claim within 5 days of receipt. Speedway Motors assumes no liability after this 5 day period.

REFUSALS All refused packages will be billed the freight to and from the destination and refused COD orders will be billed a 15% restocking charge plus freight to and from destination.

WARRANTY CLAIMS If the item is used or installed and a warranty claim request is submitted, warranty work is done by the manufacturer and may take up to 30 days for processing. Speedway Motors will be required to follow the manufacturer's warranty instructions to allow for a credit refund or exchange when specified.

Find the above info on our website:

SpeedwayMotors.com/Info/FAQ

RETURNS We want you to be satisfied with your purchase. If you are not satisfied, you may return your new, unused item within 60 days for refund or exchange.

All exchanged or returned merchandise must be in original factory condition with no modifications or alterations. Returned merchandise must include original packaging materials, warranty cards, manuals, instructions, etc. If the returned item requires repackaging, your refund / exchange will be subject to a repackaging charge. Return/Exchange transactions less than \$99 are excluded from the free shipping offer.

HOW TO RETURN AN ITEM Please re-pack the item in a sturdy box, include a copy of your invoice and completed return form. Returns must be shipped prepaid. CODs are not accepted. Shipping costs for exchanged merchandise will be charged to your credit card.

Items that are returned after 60 days are subject to a 15% restocking charges. Fiberglass items returned will be subject to a 15% restocking charge. We are unable to accept returns on electrical parts, video tapes, DVD's, books, special order or closeout merchandise.

BRAKE INSTALLATION ALERT The selection and installation of brake components should only be done by personnel experienced in the proper installation and operation of braking systems. The installer must use his/her own discretion to determine the suitability of all brake components and brake kits for every particular application. Speedway Motors, Inc. makes no warranties either expressed or implied including any warranty of merchantability or fitness for a particular purpose, other than those contained in its current catalog or website with respect to the goods identified on the face of the invoice. There is no warranty expressed or implied as to whether the goods sold hereby will protect the purchaser or ultimate user of such goods from injury or death.

EXHAUST INSTALLATION ALERT Exhaust systems and other component surface finishes are not permanent. Coatings, paint and other factory supplied cosmetic treatments are only intended to protect from surface corrosion in an unused state. No returns are allowed after the parts have been installed. Header flanges must be clean and clear of paint and surface contaminants prior to mating to exhaust gaskets. Exhaust fasteners must be re-torqued after the initial heat cycle and regularly thereafter to ensure a proper gasket seal is maintained. Should you decide to install this exhaust product at your home, be warned that pleasure car or light duty truck/van "bumper" jacks are intended for emergency use only. The use of frame contact jack stands in conjunction with a floor jack as a main support is highly recommended to minimize accidental dropping of a vehicle while the installation proceeds. We recommend the use of a shop hoist if possible. Please use caution! Speedway Motors, Inc. makes no warranties either expressed or implied including any warranty of merchantability or fitness for a particular purpose, other than those contain in its current catalog or website with respect to the goods identified on the face of the invoice. There is no warranty expressed or implied as to whether the goods sold hereby will protect the purchaser or ultimate user of such goods from injury or death.

CHECK LOCAL LAW Some parts are not legal for sale or use in California on any pollution controlled motor vehicles. These items are legal in California for racing vehicles only which may never be used upon a highway. Check local law.

© 2019, Speedway Motors, Inc.

Speedway Motors, Inc.

P.O. Box 81906 • Lincoln, NE 68501

800.979.0122 • SpeedwayMotors.com

